

# AlkaClean™ Additive 2500

## Defoamer/Antifoamer

Product Number 1861

AlkaClean™ Additive 2500 is a biodegradable, non-silicone based, nonionic surfactant concentrate that exhibits superior defoaming and antifoaming properties as well as excellent wetting action. AlkaClean™ Additive 2500 is primarily designed to be used with alkaline cleaners.

### Benefits

- Used at very low dosages (~1 oz/35 gal)
- Aids with greasy, fatty, and oily soil removal during CIP cleaning
- Versatile: Controls foam regardless of when it is applied during the alkaline CIP cycle.
- Does not interfere with wastewater treatment

### Features

- Efficient defoaming: inhibits foaming after it has occurred during CIP cleaning
- Superior antifoaming: prevents foaming from occurring during CIP cleaning
- Non-silicone based: Non-toxic formula
- Biodegradable

### Properties

- Appearance ..... Clear, colorless to light yellow liquid
- pH (5% w/w in DI water) ..... 7 – 10

### Directions for Use

#### Method

Designed to eliminate foam in CIP systems and other cleaning applications. Works well in a wide range of pH and temperatures, including high temperature caustic solutions typically found in CIP applications. Agitation while adding AlkaClean™ Additive 2500 may be necessary to solubilize the defoamer into the wash solution and dissipate foam. For low turbulence addition points such as CIP tanks, dilute Alka Clean Additive 2500 with 5 to 10 parts water to 1 part product before adding to the wash solution.

### Concentration

To control excess foam in a solution, add 1 ounce to 35 gallons CIP solution. Adjust dosage to meet required results

**Consult your DeLaval Cleaning Solutions representative for questions on specific applications.**

## Safety Information

### IF IN EYES

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention..

### IF SWALLOWED

Call a Poison Control Center or doctor/physician if you feel unwell. Rinse mouth.

### IF ON SKIN

Wash with plenty of soap and water. If skin irritation occurs: Get medical advice/attention. Take off contaminated clothing and wash before reuse


Consult your [Safety Data Sheet](#) for additional safety information

For more information about this product or any of our other products and services please visit our website at [www.delavalcleaningsolutions.com](http://www.delavalcleaningsolutions.com) or contact us at 1-800-447-8370.



DeLaval Cleaning Solutions a  
division of DeLaval Inc.  
11100 North Congress Avenue  
Kansas City, MO 64153-1296  
Phone: 1-800-447-8370

<https://cleaningsolutions.delaval.com/>

 is a registered trademark of TetraLaval Holdings & Finance S.A. and "DeLaval" is a registered trade/service mark of DeLaval Holding AB  
© 2016 DeLaval Inc. DeLaval, 11100 North Congress Avenue, Kansas City, Missouri 64153-1296.  
[www.delaval-us.com](http://www.delaval-us.com).