## **IODOFOAM**

## High-Foaming Phosphoric Acid and Iodine Detergent

DESCRIPTION IODOFOAM is a phosphoric acid containing iodine detergent formulated to generate

a thick clinging foam when applied through doorway foaming systems and/or foam generating equipment. IODOFOAM may be applied as an acid foam cleaner to clean and brighten stainless steel. IODOFOAM is a superior one-step product offering the benefit of visual indication for use in foot baths or through doorway foaming systems as

an environmental organism control product.

DIRECTIONS IODOFOAM is designed for use in foot baths, through doorway foam systems, foam

generating equipment and as a manual cleaner.

Procedure: Foam and Manual Cleaning: After cleaning, post-rinse with potable

water. Sanitize as required.

<u>Foot Baths and Doorway Foam Systems</u>: Mix or apply at 2 to 4 oz.

per gallon for 15 to 30 ppm titratable iodine.

Concentration: 2 to 4 oz. per gallon by volume for 15 to 30 ppm titratable iodine.

Temperature: 41° to 110°F. Do not heat iodine solution above 120°F.

SAFETY UTILIZE APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT AS PER SDS.

INFORMATION HANDLE AND STORE AS INDICATED ON PRODUCT LABEL.

<u>IF ON SKIN</u>: In case of contact, immediately flush skin with plenty of water for at least 15 minutes while removing contaminated clothing and shoes. Get medical attention. Wash clothes before reusing.

<u>IF IN EYES</u>: In case of contact, immediately flush with plenty of water for at least 15 minutes. Get immediate medical attention.

<u>IF SWALLOWED</u>: Drink large quantities of water. Do not induce vomiting. Never give anything by mouth to an unconscious person. Get immediate medical attention.

<u>IF INHALED</u>: Immediately move to fresh air. If not breathing, give artificial respiration, preferably mouth-to-mouth. If breathing is difficult, give oxygen. Get immediate medical attention.

Consult your Safety Data Sheet for additional safety information.

